



1. Insert the Cam Lock through Double-D Hole. **If there is a round hole this installation will not work. Stop and consult with Kenstan (516)576-9090.**
2. Slide Large 3-tab washer over the cam lock.
3. Install 3/4" Hex nut and tighten. Then fold over tabs on the 3-tab washer to prevent the nut from backing out. (See Fig. 2).
4. **Note! Rotation Stop cam should already be installed on the lock, if it isn't please do so now testing with a key for a 90° right hand rotation.** Install the CAM adapter onto the threaded tail of the cam lock.
5. Install the 2-bar from the original installation as shown in the locked position.
6. Slide Small 3-tab washer over the cam lock threaded tail.
7. Install cam hex nut and tighten. Then fold down the tabs on the 3-tab washer (See Fig. 2).

Kenstan Lock Company

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF KENSTAN LOCK CO. ANY
 REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF KENSTAN LOCK CO. IS PROHIBITED.

MATERIAL
 FINISH
 DO NOT SCALE DRAWING

NAME	DATE
AUTHOR A.M.A.	07/26/2103
UNLESS OTHERWISE SPECIFIED:	
DIMENSIONS ARE IN INCHES	
TOLERANCES:	
FRACTIONAL ± 1/64	
ANGULAR: ± 1/2° BEND ± 0.01	
TWO PLACE DECIMAL ± .01	
THREE PLACE DECIMAL ± .002	

TITLE: CLK3051 203PNY M(ETAL)		
SIZE	DWG. NO.	REV
A	Wal-Mart 0054 Installation	A
SCALE: 1:1	WEIGHT:	SHEET 4 OF 7